

updater.zip

Contains files used to update the device TRACE M4.

Procedure:

1) Unzip the zip file. You get a folder "updater". The updater is designed to update the unit.

2) Copy the folder "updater" in the root directory of a USB stick

3). Insert the USB stick into the TRACE M4 and turn on the device. After booting (white LED), the LED changes to red. Turn it off again and repeat the process until after booting a traffic light signal red, yellow, green appears.

(Note: The traffic signal serves as verification that the USB stick has been detected properly. Sometimes USB memory sticks boot too slowly and it may happen that the TRACE M4 does not realize it has a USB Stick with further instructions on board. In this case several attempts are necessary.)